

Troubleshooting with the rx2800 Management Processor

Overview

- Identify a VMS workstation running VMS 8.4-2 or newer.
- In a VMS workstation, setup to log your session to a file (`SET H 0/LOG`).
- Connect to the Management Processor (MP).
- Go to the Command Menu (CM) prompt.
- Get a list of available commands (`HELP LIST` or `HE LI`).
- View Power Status (PS).
- Return to the MP Main Menu.
- View the Virtual Front Panel (VFP).
- Cancel VFP and return to the MP Main Menu.
- Dump and save the Event Log.
- Clear the log files.
- Enter the CM and view the rx2800 firmware revisions (`SYSREV`).
- In the CM, view the listing of the hardware installed in the rx2800 (`DF -ALL`).
- Exit the MP session.
- Finish logging the VMS workstation session.
- Review the session log file.

Details

1. Identify a VMS workstation running VMS 8.4-2 or newer – required for SSH to work with the rx2800 MP.

```
PDQVS1$ tcpip show version
HP TCP/IP Services for OpenVMS Industry Standard 64 Version V5.7 - ECO 5 on an
HP Integrity rx2800 (1.73 GHz / 20.0 MB) running OpenVMS V8.4-2
```

- In a VMS workstation, setup to log your session to a file (SET H 0/LOG).

```
PDQVS1$ set h 0/log=mp-troubleshoot-pdqvsa-log.txt

Welcome to HP OpenVMS Industry Standard 64 Operating System, Version V8.4-2

Username: system
Password:
VMS Software, Inc. OpenVMS (TM) IA64 Operating System, V8.4-2 on node PDQVS1
Last interactive login on Monday, DECEMBER 3, 2018 04:06 PM
Last non-interactive login on Sunday, DECEMBER 9, 2018 03:03 AM
1 failure since last successful login

PDQVS1$
```

- Connect to the Management Processor (MP).

Per usual convention, the PDQVSA MP Hostname is PDQVCA.

```
PDQVS1$ ssh "Admin@pdqvca"
...
Admin's password: (Keystrokes will not be echoed, no asterisks or dots, nothing.)
Authentication successful.

Hewlett Packard Enterprise Integrated Lights-Out 3 for Integrity
(C) Copyright 1999-2017 Hewlett Packard Enterprise Development, LP
MP Host Name: pdqvca
iLO Firmware Revision 02.00.03

MP MAIN MENU:

CO: Console
VFP: Virtual Front Panel
CM: Command Menu
CL: Console Log
SL: Show Event Logs
HE: Main Help Menu
X: Exit Connection
```

- Go to the Command Menu (CM) prompt.

```
[pdqvca]</> hpiLO-> cm

(Use Ctrl-B to return to MP main menu.)
```

5. Get a list of available commands (HELP LIST or HE LI).

```
[pdqvca] CM:hpiLO-> he li

HE li

==== MP Help: Command Menu List =====

CA  : Configure asynch/serial ports      PM  : Power Management
DATE: Display Date                      PR  : Power Restore Configuration
DC  : Default Configuration              PS  : Power management module Status
DI  : DIscconnect users                  RS  : Reset System through RST signal
DF  : Display FRU Information             SA  : Set MP Access
DNS : Configure DHCP and DNS             SO  : Security Options
FW  : Upgrade MP firmware                 SS  : System processors Status
HE  : Display Help                       SYSREV: Display System firmware Revs.
ID  : System Information                  SYSSET: System Settings
IT  : Modify MP inactivity timeouts       TC  : Reset system via INIT
LC  : Configure LAN, SSH and Web ports    TE  : TELL- send a msg. to other users
LDAP: Configure Directory parameters      UC  : User Configuration
LM  : License Management                  WHO  : Display connected MP users
LOC : Locator UID LEDs display           WOL  : Wake-On-LAN
LS  : LAN Status                          WSMAN : WSMAN notification settings
OEMSYSSET: OEM System Settings           XD  : Diagnostics and reset of MP
PC  : Remote Power Control
```

6. View Power Status (PS).

```
[pdqvca] CM:hpiLO-> ps

PS
For System Processor Status see the SS command.

System Power state   : On
System Power usage   : 159 Watts
Ambient temperature  : 14 C
Temperature status   : Normal

Power supplies          State
-----
Power Supply 1         Normal
Power Supply 2         Normal

Fans                   State
-----
Fan Unit 1            Normal
Fan Unit 2            Normal
Fan Unit 3            Normal
Fan Unit 4            Normal
Fan Unit 5            Normal
Fan Unit 6            Normal

[pdqvca] CM:hpiLO->
```

7. Return to the MP Main Menu.

```
[pdqvca] CM:hpiLO-> <Ctrl-B>
```

MP MAIN MENU:

```
CO: Console
VFP: Virtual Front Panel
CM: Command Menu
CL: Console Log
SL: Show Event Logs
HE: Main Help Menu
X: Exit Connection
```

8. View the Virtual Front Panel (VFP).

```
[pdqvca]</> hpiLO-> vfp
```

Welcome to the Virtual Front Panel (VFP).
Use Ctrl-B to exit.

System state	Activity	# of logs since boot
Boot complete	OS_BOOT_COMPLETE	673

E indicates error since last boot

LEDs	LOCATOR	SYSTEM	HEALTH	POWER
	OFF	ON GREEN	ON GREEN	ON GREEN

Status | SYS:OS Booting or Running
 | HLT:System health is okay
 | POW:System Power on

(Use '?' to display VFP terminal info or Ctrl-B to Quit)

9. Cancel VFP and return to the MP Main Menu.

```
[pdqvca] VFP:hpiLO-> <Ctrl-B>
```

MP MAIN MENU:

```
CO: Console
VFP: Virtual Front Panel
CM: Command Menu
CL: Console Log
SL: Show Event Logs
HE: Main Help Menu
X: Exit Connection
```

10. Dump and save the Event Log.

```
[pdqvca] hpiLO-> sl
Event Log Viewer Menu:
-----
Log Name          Entries    % Full    Latest Timestamped Entry
-----
E - System Event   270       10 %     09 Dec 2018 18:15:17
F - Forward Progress 12918     65 %     09 Dec 2018 18:15:17
I - iLO Event      169       33 %     09 Dec 2018 18:11:53
C - Clear SEL and FPL
L - Live Events

Enter menu item or [Ctrl-B] to Quit: e
-----
Log Name          Entries    % Full    Latest Timestamped Entry
-----
E - System Event   270       10 %     09 Dec 2018 18:15:17

Event Log Navigation Help:
+      View next block      (forward in time, e.g. from 3 to 4)
-      View previous block (backward in time, e.g. from 3 to 2)
<CR>  Continue to the next or previous block
D      Dump the entire log
F      First entry
L      Last entry
J      Jump to entry number
H      View mode configuration - Hex
K      View mode configuration - Keyword
T      View mode configuration - Text
S      View mode configuration - Cause/Action
A      Alert Level Filter options
U      Alert Level Unfiltered
?      Display this Help menu
Q      Quit and return to the Event Log Viewer Menu
Ctrl-B Exit command, and return to the MP Main Menu
```

11. Clear the log files.

```

SL:hpiLO (+,-,<CR>,D,F,L,J,H,K,T,S,A,U,?,Q or Ctrl-B to Quit)->t
SL:hpiLO (+,-,<CR>,D,F,L,J,H,K,T,S,A,U,?,Q or Ctrl-B to Quit)->d
  Confirm? (Y/[N]): y

Log Entry 1: 21 Feb 2018 10:53:53
Alert Level 2: Informational
Keyword: ILO_SOFT_RESET
integrated Lights Out firmware soft reset occurred.
Logged by: integrated Lights Out
Data: Data field unused
4080256900E10001 0000000000000000

Log Entry 2: 21 Feb 2018 10:54:25
Alert Level 2: Informational
Keyword: ILO_IS_BOOTING
iLO is part way through booting up after a reset or power on event.
Logged by: integrated Lights Out
Data: Data field unused
408022AE00E10003 0000000000000000

...

Log Entry 270: 09 Dec 2018 18:15:17
Alert Level 2: Informational
Keyword: OS_BOOT_COMPLETE
OS Boot Complete
Logged by: O/S Kernel (Generic)
Data: Major change in system state - Boot Complete
548016E100E101E3 0000000000000001

-> This is the last entry in the selected log.
SL:hpiLO (+,-,<CR>,D,F,L,J,H,K,T,S,A,U,?,Q or Ctrl-B to Quit)->q

Event Log Viewer Menu:

      Log Name              Entries    % Full    Latest Timestamped Entry
-----
E - System Event           270        10 %      09 Dec 2018 18:15:17
F - Forward Progress      12918       65 %      09 Dec 2018 18:15:17
I - iLO Event              169         33 %      09 Dec 2018 18:11:53
C - Clear SEL and FPL
L - Live Events

Enter menu item or [Ctrl-B] to Quit: c
Are you sure you want to clear the System Event Log and Forward Progress Log?
(Y/[N]): y

-> Logs have been cleared.

```

12. View the rx2800 firmware revisions (SYSREV).

```
[pdqvca] CM:hpiLO-> sysrev

SYSREV

Revisions      Active      Pending
-----
iLO FW         : 02.00.03
System FW      : 02.68
MHW FPGA       : 02.02
Power Mon FW   : 02.09
PRS HW         : 02.08
IOH HW         : 02.02
Power Supply 1 : 02.01
Power Supply 2 : 02.01
```

13. View the listing of the hardware installed in the rx2800 (DF -ALL).

```
[pdqvca] CM:hpiLO-> df -all

DF -all

FRU NAME: System Board ID: 00

CHASSIS INFO:
Type:                Rack Mount Chassis
Part Number          : AT101-2000A
Serial Number        : SGH808V6BK
Custom Info          : 0

BOARD INFO:
Mfg Date/Time        : 22-Nov-2017 06:48 (11514648)
Manufacturer          : INVENTEC
Product Name          : rx2800 System Board
S/N                   : MS7BNK0235
Part Number           : AT101-60001
Fru File ID           : 11
Custom Info           : C01
Custom Info           : 5407
Custom Info           : E1
Custom Info           : 0

PRODUCT INFO:
Manufacturer          : hp
Product Name          : Integrity rx2800
Part/Model            : AT102A
S/N                   : SGH808V6BK
FRU File ID           : 11
Custom Info           : 891

Type <CR> for next entry, or Q to quit:
FRU NAME: SAS Backplane ID: 01
...
```

RX2800 TROUBLESHOOTING

(Note: the SN of this rx2800 is SGH8080V6BK.)

...

-> Command successful.

14. Exit the MP session.

```
[pdqvca] CM:hpiLO-> <Ctrl-B>
```

```
MP MAIN MENU:
```

```
CO: Console
VFP: Virtual Front Panel
CM: Command Menu
CL: Console Log
SL: Show Event Logs
HE: Main Help Menu
X: Exit Connection
```

```
[pdqvca]</> hpiLO-> x
```

```
Disconnected; by application ( Client Disconnect).
```

```
Connection to 192.0.200.227 closed.
```

```
PDQVS1$
```

15. Finish logging the VMS workstation session.

```
PDQVS1$ logout
```

```
SYSTEM logged out at DECEMBER 9, 2018 10:57 AM
```

```
%REM-S-END, control returned to node PDQVS1::
```

```
PDQVS1$
```


16. Review the session log file.

```
PDQVSA$ TYPE/PAGE MP-TROUBLESHOOT-PDQVSA-LOG.TXT

Welcome to HP OpenVMS Industry Standard 64 Operating System, Version V8.4-2

Username: system
Password:
VMS Software, Inc. OpenVMS (TM) IA64 Operating System, V8.4-2 on node CPCVSB
Last interactive login on Monday, DECEMBER 3, 2018 04:06 PM
Last non-interactive login on Sunday, DECEMBER 9, 2018 03:03 AM
1 failure since last successful login
You have 2 new Mail messages.

CPCVSB$
CPCVSB$ ssh "Admin@192.0.200.227
MP MAIN MENU:

CO: Console
VFP: Virtual Front Panel
CM: Command Menu
CL: Console Log
SL: Show Event Logs
HE: Main Help Menu
X: Exit Connection

[pd
qvca]</> hpiLO->
c
m
...

PDQVS1$
```