

Forcing Password Use of a Terminal Server

Define/Set/Change Server Login Password

LOGIN PASSWORD changes the password that interactive users type at login, if their ports have PASSWORD ENABLED.

```
LOGIN PASSWORD [ "password" ]
```

For the password, enter a string 1 to 16 keyboard characters. You can enter the password on the command line within quotation marks ("), or enter the password at a prompt if it is the only characteristic in the command line.

The default password is ACCESS.

Define/Set/Change Port Password

PASSWORD determines whether a password is required for the port user to log in.

```
PASSWORD {ENABLED }  
          {DISABLED} *
```

ENABLED user must enter login password.

DISABLED user is not prompted for a password.