
Off	No power or display broken
B	Initial power on
F	Initialization
E	DECserver 700 internal test
d	SIM 1 test
C	SIM 2 test
b	DECserver 700 internal test
R	DECserver 700 internal test
9	DECserver 700 internal test
7	DECserver 700 internal test
S	NI external test
≡	Firmware loading from Flash RAM
4	Requesting load
3	Load request backoff
2	Loading
1	Requesting dump
0	Dumping
H	Hardware revision number incompatible with firmware revision number
n	No SIMs or wrong type SIMs installed
ROTATING	DECserver 700 is operating correctly
