

1. Copying Graphics Databases from MISER VMS Workstations to a PC

This operation needs to be done if:

- the PC is running local XviewNT graphics databases, usually true of a dial-in PC and not true of a network PC, and
- you want Xdraw modifications done on the host to be visible on the PC.

The Procedure:

1. Ensure that no one is using Xview on the workstation from which you will be copying the graphics files.
2. Dial in as if to use XviewNT, but do not run XviewNT.
3. Open a DOS window.
4. CD C:\XVIEWNT\MISER\VIEW
5. RENAME XSLIDE.DAT XSLIDE.DA0
6. RENAME XSLIDE.NDX XSLIDE.ND0
7. (If the symbol database has been changed) RENAME XSYMBL.DAT XSYMBL.DA0
8. (If the symbol database has been changed) RENAME XSYMBL.NDX XSYMBL.ND0
9. FTP <MISER workstation>
10. Log in.
11. FTP> CD SITE\$VIEW:
12. FTP> BIN
13. FTP> HASH
14. FTP> PROMPT

15. FTP> MGET XSLIDE.*

16. (If copying symbol database) FTP> MGET XSYMBL.*

17. FTP> BYE

18. XviewNT should now work with the new slides.