

1. Starting RTUdiag on a Laptop

This document assumes the user is using either Windows 98 or 95.

- 1.) Upon Power Up of the laptop PC, hold down the F8 Function Key. If the 'Windows' screen pops up, reboot the computer and press the F8 Function Key as soon as the restart starts.
- 2.) A screen showing five choices of direction appears. Go to the Command Prompt only selection.
- 3.) A DOS propt appears:

```
C:\>
```

- 4.) Enter at the prompt:

```
C:\>CD RTU
```

This changes the root directory to the RTU directory.

- 5.) Then, enter:

```
C:\rtu>cd rtudiag
```

This changes the RTU directory to the RTUdiag directory.

- 6.) In the RTUdiag directory, enter:

```
C:\rtu\rtudiag>rtudiag
```

This starts the RTUdiag application. Because RTUdiag is mainly a DOS program, it does not operate correctly under the Windows program.